



Setup Guide

設定指南 / セットアップガイド /
 Manuel de configuration / Guía de
 configuración / Guide d'installation /
 Installatiehandleiding / Einrichtungshandbuch /
 Guia de configuração / Guida di installazione /
 Startguide / Installationsvejledning /
 Asetusopas / Innstillingsveiledning /
 Przewodnik ustawień / Průvodce nastavením /
 Sprievodca nastavením / Beállítási útmutató /
 Ghid de configurare / Ръководство за
 настройка / Οδηγός εγκατάστασης / Kurulum
 Kılavuzu / Seadistusjuhend / Uzsākšanas
 ceļvedis / Nustatymo vadovas / Priročnik za
 pripravo / Vodič za postavljanje / Vodič za
 podešavanje / מודריך הגדרה


Monitor con pantalla de cristal líquido (LCD)

Lea este manual antes de usar el producto




1.5 N·m/1,5 N·m
{15 kgf·cm}


1





2




3




1






2



4



5



https://rd1.sony.net/help/tv/f27m30/h_zz/