

## 日本語

**V2.0 で更新される主な機能****バージョンアップに関してのご注意**

V2.0 にバージョンアップする場合は、必ずバージョンアップガイド「4-736-142-01(1)」に従って操作を行ってください。

**MPC-3610 (VENICE/CineAltaV) の Ver2.0 に対応**

MPC-3610 (VENICE/CineAltaV) と接続することで、以下のイメージャーモードでの記録が可能になりました。

- 4K 6:5 Anamorphic
- 6K 1.85:1
- 6K 17:9

なお、詳細は MPC-3610 (VENICE/CineAltaV) の取扱説明書をご覧ください。

**AXS-R7 のバージョンアップ**

MPC-3610 (VENICE/CineAltaV) (Ver2.0 以降) と接続することで、AXS-R7 のバージョンアップが可能になりました。なお、詳細は MPC-3610 (VENICE/CineAltaV) の取扱説明書をご覧ください。

**V1.10 で更新される主な機能****MPC-3610 (VENICE/CineAltaV) に対応**

MPC-3610 (VENICE/CineAltaV) と接続して、RAW および X-OCN の映像・音声を記録できるようになりました。

X-OCN は、6K 3:2 での記録も可能です。

なお、記録可能なフォーマットは MPC-3610 の取扱説明書をご覧ください。

**Software Version データの記録**

Software Version データを RAW クリップまたは X-OCN クリップに記録できるようになりました。

## English

**Major Functions Updated in V2.0****Precautions when updating**

When updating to V2.0, follow the instructions described in the update guide (4-736-142-11(1)).

**Support for MPC-3610 (VENICE/CineAltaV) Ver. 2.0**

Recording in the following imager modes is supported when the unit is attached to the MPC-3610 (VENICE/CineAltaV).

- 4K 6:5 Anamorphic
- 6K 1.85:1
- 6K 17:9

For details, refer to the operating instructions for the MPC-3610 (VENICE/CineAltaV).

**Updating the AXS-R7**

The AXS-R7 can now be updated while attached to the MPC-3610 (VENICE/CineAltaV) (Ver. 2.0 or later).

For details, refer to the operating instructions for the MPC-3610 (VENICE/CineAltaV).

**Major Functions Updated in V1.10****Support for MPC-3610 (VENICE/CineAltaV)**

The ability to connect to MPC-3610 (VENICE/CineAltaV) and record RAW and X-OCN video/audio was added.

6K 3:2 recording is also possible for the X-OCN format.

For details on supported recording formats, refer to the operating instructions for the MPC-3610.

**Recording software version data**

The ability to record software version data to RAW clips and X-OCN was added.